

Weidmüller Interface GmbH & Co. KG
Klingenbergstraße 16
D-32758 Detmold
+49 5231 14-0
+49 5231 14-29203
info@weidmueller.de



<http://wmgr.eu/242550>

Weidmüller

Energy Analyser 550

Schnelleinstieg

Ergänzung zur Betriebsanleitung

- Installation
- Kommunikations-Einstellungen über Ethernet
- Software „ecoExplorer go“-Einstellungen (siehe Link und QR-Code)



www.weidmueller.com

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550

242550</p

2

General

This "Quick guide" does not replace the operating manual. First, please read and ensure that you understand the operating manual that accompanies the product.

Disclaimer

The observance of the information products for the devices is a prerequisite for safe operation and to achieve the stipulated performance characteristics and product characteristics. Weidmüller Interface GmbH & Co. KG accepts no liability for injuries to personnel, property damage or financial losses arising due to a failure to comply with the information products. Ensure that your information products are accessible and legible.

Further information can be found on our website www.weidmueller.de.

Copyright notice

© 2016 - Weidmüller Interface GmbH & Co. KG - Detmold. All rights reserved. Duplication, editing, distribution and any form of exploitation, also as excerpts, is prohibited.
Subject to technical amendments

Note that this document may not always be updated at the same time as technological developments. Information and specifications may change. Please check for the latest version at www.weidmueller.de.

Disposal

Please observe national regulations! If disposing of individual parts, please dispose of them in accordance with their nature and existing country-specific regulations, for example as:

- Electrical scrap
- Plastics
- Metals

Or, task a certified disposal business with the scrapping.

Relevant laws, applied standards and directives

The laws, standards and directives for the device applied by Weidmüller Interface GmbH & Co. KG can be found in the declaration of conformity.

<h2>Safety</h2>							
<h3>Safety information</h3> <p>The "Quick guide" does not represent a full listing of all necessary safety measures required for safe operation of the device. Certain operating conditions may require further measures. The "Quick guide" contains information that you must observe for your own personal safety and to avoid damage to property.</p>							
<p>Symbols used:</p>							
 This symbol is used as an addition to the safety instructions and warns of an electrical hazard.							
 This symbol is used as an addition to the safety instructions and warns of a potential hazard.							
 This symbol with the word NOTE! describes: <ul style="list-style-type: none">• Procedures that do not entail any danger of injury.• Important information, procedures or handling steps.							
<p>Safety instructions are highlighted with a warning triangle and shown as follows, depending on the degree of hazard:</p>							
<table border="1"><tr><td></td><td>Indicates an immediately threatening hazard that leads to serious or even fatal injuries. DANGER!</td></tr><tr><td></td><td>Indicates a potentially hazardous situation that could lead to serious or even fatal injuries. WARNING!</td></tr><tr><td></td><td>Indicates a potentially hazardous situation that could lead to minor injuries or damage to property. CAUTION!</td></tr></table>			Indicates an immediately threatening hazard that leads to serious or even fatal injuries. DANGER!		Indicates a potentially hazardous situation that could lead to serious or even fatal injuries. WARNING!		Indicates a potentially hazardous situation that could lead to minor injuries or damage to property. CAUTION!
	Indicates an immediately threatening hazard that leads to serious or even fatal injuries. DANGER!						
	Indicates a potentially hazardous situation that could lead to serious or even fatal injuries. WARNING!						
	Indicates a potentially hazardous situation that could lead to minor injuries or damage to property. CAUTION!						
<h3>Measures for safety</h3> <p>When operating electrical devices certain parts of these devices inevitable carry dangerous voltages. This could result in serious bodily injury or damage to property if not handled properly:</p> <ul style="list-style-type: none">• Before establishing electrical connections to the device, earth it at the ground wire connection if there is one.• Hazardous voltages may arise in all circuit parts that are connected to the power supply.• Even after disconnecting the supply voltage, there may still be hazardous voltages present in the device (capacitor storage).							

3

not operate equipment with current
transformer circuits when open.
not exceed the limit values stipulated in
operating manual - even during testing or
commissioning.
observe the safety and warning information in
documents that belong to the devices!

Qualified personnel
In order to avoid injuries to personnel and
property damage, only qualified personnel with
adequate training are permitted to work on the
device with knowledge
of the national regulations for accident
prevention
and safety standards
of installation, commissioning and operation
of the device.

Proper use

The device is

- intended for installation in switch cabinets
and small installation distributors (please
observe step 3 "Installation").
- not intended for installation in vehicles!
The use of the device in mobile equipment
is considered to be non-standard
environmental conditions and is therefore
only permitted after separate agreement.
- not intended for installation in environments
with hazardous oils, acids, gases, vapours,
dusts, radiation, etc.

The prerequisites of faultless, safe operation
of this device are proper transport and proper
storage, set-up, installation, operation and
maintenance.

4

brief description of device

The device is a multi-functional network power meter, which measures and calculates electrical variables such as voltage, current, power, energy, harmonics, etc. in building installations, on distribution units, circuit breakers and busbar trunking systems.

Prerequisite:
Measured voltages and measured currents come from the same network.

The device delivers measurement results, which can be displayed, saved and transmitted via interfaces.

NOTE!
Detailed information on the device functions and data can be found in the operating manual.

Installation

Install the device in the weather-protected front panel of switch cabinets.

Cut-out size:
 $138^{+0.8} \times 138^{+0.8}$ mm

Ensure!
Adequate ventilation

- The device is installed vertically!
- Observance of clearance to adjacent components!

Fig. Installation situation, rear view

CAUTION!  **Damage to property due to disregard of the installation instructions**

Disregard of the installation instructions can damage or destroy your device.

Ensure that you have enough air circulation in your installation environment and in the event of high environmental temperatures, provide cooling if necessary.

Danger of injury due to electrical voltage!

WARNING!

serious bodily injury or death can result from
Contact with bare or stripped live wires.
Device inputs that are dangerous to touch.
**Render the system free of voltage before
starting work! Check the system is free of
electrical energy!**

Fig. Connection of supply voltage.

CAUTION! **Damage to property due to disregard of the connection conditions or impermissible overvoltage**

Your device can be damaged or destroyed by a failure to comply with the connection conditions or by exceeding the permissible voltage range.

Before connecting the device to the supply voltage, check:

- The ground wire connection must be connected with the system earthing!
- Voltage and frequency correspond to the details on the ratings plate! Limit values stipulated in the operating manual have been complied with!
- In building installations, the supply voltage must be protected with a UL approved circuit breaker / a fuse (6 A, type C)!
- The isolation device
 - must be installed near the device and in a location that is easily accessible for the user.
 - must be labelled to identify the respective device.
- Do not tap the supply voltage from the voltage transformer.
- Provide a fuse for the neutral conductor if the neutral conductor terminal of the source is not grounded.

6

Mains systems

Mains systems and max. rated voltages (DIN EN 61010-1/A1):

Three-phase, four-conductor system with earthed neutral conductor U_{L-N} / U_{L-L} 417 VLN / 720 VLL	Three-phase, four-conductor system with non-earthed neutral conductor Only partially suitable for use in non-earthed networks (see step 7).	Three-phase, three-conductor systems Non-earthed U_{L-L} 600 VLL	Three-phase, three-conductor systems With earthed phase U_{L-N} / U_{L-L} 240 VLN / 480 VLL
Two-phase, two-conductor systems Non-earthed Only partially suitable for use in non-earthed networks (see step 7).	Single-phase, two-conductor systems with earthed neutral conductor U_{L-N} 230 VLN	Separated single-phase, three-conductor systems with earthed neutral conductor U_{L-N} / U_{L-L} 240 VLN / 480 VLL	Application areas for the device: <ul style="list-style-type: none"> • 2, 3 and 4 conductor networks (TN and TT networks). • In residential and industrial applications.

Voltage measurement

The device has 4 voltage measurement inputs and is suitable for various connection variants.

Danger of injury or damage to the device

CAUTION!
Disregard of the connection conditions for the voltage measurement inputs can result in injuries or to the device being damaged. For this reason, note that:

- **Do not connect the voltage measurement inputs**
 - to DC voltage.
 - Do not use for voltage measurement in SELV circuits (safe extra low voltage).
- Voltages that exceed the allowed network rated voltages be connected via a voltage transformer.
- The voltage measurement inputs are to be equipped with a suitable, labelled fuse and isolation device located in the vicinity.

NOTE!
A 10 A (type C) circuit breaker can be used as an alternative to a fuse and isolating device.

Fig. Connection example "Voltage measurement".

The voltage measurement inputs are designed for measurements in low voltage networks where rated voltages of up to

- 417 V phase to earth and 720 V phase to phase in 4-conductor systems or
- 600 V phase to phase in 3-conductor systems can occur.

The rated voltages and surge voltages comply with the overvoltage category 600 V CATIII.

8

Schematic diagram for voltage measurement

Voltage measurement in the three-phase, conductor system (TN, TT networks).

Earth your system!

Schematic diagram, device in a TN network.

RECOMMENDATION!

For a PE/N measurement, connect the protective earth (PE) to measurement input V4. Do not use a green/yellow wire for this as the conductor does not have any protective function!

Voltage measurement in the three-phase, three-conductor system (IT network).

The device is only suitable to a limited extent for use in IT networks, since the measured voltage relative to the housing potential is measured and the input impedance of the device creates residual current against the earth. The residual current can trigger the insulation monitoring in IT networks.

Connection variants with voltage transformers are suitable for IT networks without restrictions!

Fig. Schematic diagram, device in an IT network without N.

9

Other connection variants for voltage measurement

Three-phase, four-conductor system	Single-phase, three-conductor system	Three-phase, five-conductor system
<p>3p 4w</p> <p>3p 4wu</p>	<p>1p 2w</p>	<p>3p 5w</p>

Three-phase, three-conductor system
<p>3p 3w</p> <p>3p 3wu</p>

The device requires the mains frequency (range from 40 Hz to 70 Hz) for the measurement and calculation of measured values.

It is not necessary to configure a connection schematic for measurement input V4!

Current measurement

device
is intended for the connection of current transformers with secondary currents of ..1 A and ..5 A.
does not measure DC.
current measurement inputs can be loaded
max. 120A for 1 second.

DANGER! Danger of injury due to electrical voltage!

serious bodily injury or death can result from:
Contact with bare or stripped live wires.
Current measurement inputs on the device and on the current transformer that are dangerous to touch.

render the system free of voltage before starting work! Check the system is free of electrical energy!





Earth the system! Use the earth connection points with earthing symbols for this!

Earth the secondary windings of current transformers and all of the metal parts of the transformer that could be touched!

17 (L ⁺) H
18 (N) A
19 (S1)
20 (S2)
21 (2S1)
22 (2S2)
23 (3S1)
24 (3S2)
25 (4S1)
26 (4S2)
27 (V1)
28 (V2)
29 (V3)
30 (V4)
31 (Vn)

Fig. Example connection "Current measurement via current transformers".

The current direction can be corrected via the serial interfaces or on the device for each phase. If incorrectly connected, a subsequent re-connection of the current transformer is not required.

Further connection variants, current measurement	
Three-phase, four-conductor system  3p 4w	Three-phase, five-conductor system  3p 5w
Three-phase, three-conductor system  3p 2i0	Single-phase, three-conductor system  1p 2i
It is not necessary to configure a connection schematic for measurement input I4!	
<div style="border: 1px solid black; padding: 10px; background-color: #ffffcc;">  NOTE! Further information on current data and current transformer data can be found in the operating manual. </div>	
<div style="border: 1px solid black; padding: 10px; background-color: #ffffcc;">  NOTE! Information for on supporting measurement (input V4/I4) can be found in the operating manual </div>	

12

Residual current monitoring (RCM) via I5 and I6

Connection variant "Residual current monitoring via current transformer"

The device is suitable for use as a residual current monitoring device (RCM) for monitoring

- AC
- pulsing DC, and
- DC.

The device measures residual currents in accordance with IEC/TR 60755 (2008-01),

Type A

Suitable residual current transformers with a rated current of 30 mA are connected to terminals 4 and 5 (I5) and terminals 6 and 7 (I6).

NOTE!

- The transformation ratios for the residual current transformer inputs can be configured via the software.
- A connection variant "**Energy Analyser 550 with residual current monitoring via measurement inputs I5/I6**" can be found in the operating manual.
- It is not necessary to configure a connection schematic for measurement inputs I5 and I6.

13

The most important technical data

Supply voltage	
Protection of the supply voltage (fuse)	6 A, type C (approved i.a.w. UL/IEC)
Installations overvoltage category	300 V CAT III
Nominal range	95 V - 240 V (45..65 Hz) or DC 80 V - 300 V
Operating range	±10% of nominal range
Power consumption	max. 7 W, max. 14 VA

Voltage measurement	
3-phase, 4-conductor systems with rated voltages (L-N/L-L)	max. 417 V/720 V (+10%)
3-phase, 3-conductor systems, unearthed (L-L) with rated voltages	max. 600 V (+10%)
Oversupply category	600 V CAT III
Rated surge voltage	6 kV
Measurement range L-N ¹⁾	0 to 600 Vrms
Measurement range L-L ¹⁾	0 to 1000 Vrms
Resolution	0.01 V
Crest factor	1.6 (related to 600 Vrms)
Impedance	4 MΩ/phase
Power consumption	approx. 0.1 VA
Sampling rate	20 kHz / phase

Voltage measurement	
Transients	> 50 µs
Frequency range of the fundamental oscillation - resolution	40 Hz to 70 Hz 0.001 Hz

1) The device measures if a voltage L-N > 10 Veff or a voltage L-L > 18 Veff is applied to at least one voltage measurement input.

Current measurement	
Nominal current	5 A
Measurement range	0.001 to 7 Arms
Crest factor	2.4
Resolution	0.1 mA
Oversupply category	300 V CAT III
Rated surge voltage	4 kV
Power consumption	approx. 0.2 VA (Ri=5 MΩ)
Overload for 1 sec.	120 A (sinusoidal)
Sampling rate	20 kHz / phase

 **NOTE!**
Further technical data can be found in the operating manual for the device.

14

Establish Ethernet connection to the PC

See most common Ethernet connections
in PC and device are described here:

```

graph LR
    PC[PC] --- EC[Ethernet (crossover patch cable)]
    EC --- EA[Energy Analyser 550]
  
```

PC and PC require a static IP address.

```

graph LR
    PC[PC] --- PC_C[Patch cable]
    PC_C --- SW[Switch/Router]
    SW --- SW_C[Patch cable]
    SW_C --- EA[Energy Analyser 550]
  
```

PC and PC require a static IP address.

```

graph LR
    PC[PC] --- PC_C[Patch cable]
    PC_C --- SW[Switch/Router]
    SW --- SW_C[Patch cable]
    SW_C --- EA[Energy Analyser 550]
  
```

PC will automatically assign IP addresses to the device and PC.

Details on device configuration and
communication can be found in section 15.

CAUTION!

**Property damage due to
incorrect network settings**

Incorrect network settings can cause faults in
the IT network!

**Find out the correct Ethernet network
settings for your device from your network
administrator.**

15

Controls and button functions

The device is operated via 6 function keys for the selecting measured value indications. Navigation within the menus. Editing device settings.

	Function
	<ul style="list-style-type: none"> • Back to home screen • Exits selection menu
	<ul style="list-style-type: none"> • Select digit (to the left) • Selects main values (U, I, P ...)
	<ul style="list-style-type: none"> • Changes (number -1) • By-values (select) • Selects menu item
	<ul style="list-style-type: none"> • Changes (number +1) • By-values (select) • Selects menu item
	<ul style="list-style-type: none"> • Select digit (to the right) • Selects main values (U, I, P ...)
	<ul style="list-style-type: none"> • Opens selection menu • Confirm selection

NOTE!
More detailed information on operation, display and button functions for your device can be found in the operating manual.

Fig. Device display - measured value indication

The figure shows the device display with the following data:

Phase	Voltage	Current	Real Power	Reactive Pow	PF
L1-N	0.02 V	0.00 A	-0.00 kW	+0.00 kvar	1.00
L2-N	0.02 V	0.00 A	-0.00 kW	+0.00 kvar	1.00
L3-N	0.03 V	0.00 A	0.00 kW	+0.00 kvar	1.00
L4-N	0.02 V	0.00 A	0.00 kW	+0.00 kvar	1.00
L1-L3	49.9 Hz	0.00 A	0.00 kW	+0.00 kvar	1.00

Below the display are labels pointing to its features:

- Measured values
- Labelling of the function keys
- Function keys

NOTE! Current and voltage transformer ratios.

The current and voltage transformer ratios can be conveniently configured via

- the menu Configuration > Measurement > Measurement transformer > Phase L1.
- the "ecoExplorer go" software.

More details on current transformers and voltage transformer ratios and their adjustment can be found in the operating manual.

Main menu	
Language	english
Communication	->
Measurement	->
System	->
Display	->
Colors	->
Extensions	->
esc	▼ ▲ enter
[ESC]	[][][][][][]

Fig. "Main menu"

Select the menu entry to adjust with the 3 and 4 buttons in the "Main menu". Confirm the selected menu entry with button 6 "Enter"!

Communication	
Ethernet (TCP/IP)	
DHCP	DHCP
Address	192.168.1.116
Netmask	255.255.255.0
Gateway	192.168.3.4
Field Bus	
RS485	Modbus Master/Gateway
Device	1
Speed	115200
esc	▼ ▲ enter
[ESC]	[][][][][][]

Fig. "Communication" window

Your device has 1 Ethernet interface and 1 RS485 interface (fieldbus) for communication, which can be adjusted in the "Communication" window.

16

Communication via Ethernet interface (TCP/IP)

The device has 3 types of address allocation for the Ethernet interface (TCP/IP) in **DHCP** mode:

- OFF (fixed IP address)**
The user selects the IP address, network mask and gateway on the device. Use this mode for straightforward networks without DHCP servers.
- BOOTP**
Automatically integrates your device into an existing network. BOOTP is an older protocol and has a smaller scope of functions than DHCP.
- DHCP**
When started, the device automatically receives the IP address, the network mask and the gateway from the DHCP server.

Standard setting for the device is DHCP!

NOTE!
Find out the correct Ethernet network settings for your device from your network administrator.

NOTE!
The description of additional communication interfaces can be found in the operating manual for your device.

Main menu

Language	english
Communication	→
Measurement	→
System	→
Display	→
Colors	→
Extensions	→

esc ▼ ▲ enter

ESC ¹	◀ ²	▼ ³	▲ ⁴	▶ ⁵	◀◀ ⁶
------------------	----------------	----------------	----------------	----------------	-----------------

Communication

Ethernet (TCP/IP)

DHCP	DHCP
Address	192.168.1.116
Netmask	255.255.255.0
Gateway	192.168.3.4

Field Bus

RS485	Modbus Master/Gateway
Device	1
Speed	115200

esc ▼ ▲ enter

ESC	◀ ²	▼ ³	▲ ⁴	▶ ⁵	◀◀ ⁶
-----	----------------	----------------	----------------	----------------	-----------------

Check the IP address of your computer

For further settings and the next steps it is important to check the IP address of your PC and to note this down if necessary.

There are 2 ways to check the IP address of your PC:

1. Via the "DOS window".
2. Via the "Control panel".

Checking the IP address via the "DOS window":

1. Press the Windows key.
2. The "Start menu" appears with the search window.
3. Enter the command "cmd" in the search window and confirm with the "Return key".
4. The "DOS window" appears.
5. Enter the command "Ipconfig" and confirm with the "Return key".
6. The IP address, the subnet mask and the standard gateway for your PC appear in the "DOS window".




Fig. MS Windows 7 - DOS window

Checking the IP address via the "Control panel":

1. Press the Windows key.
2. The "Start menu" appears.
3. Click on "Control panel" in the right menu field.
4. The "Adjust your computer's settings" window appears.
5. Click on "Network and sharing center".
6. The "Network and sharing center" window appears.



Fig. MS Windows 7 - "Network and sharing center" window

18

Click the "Details" button.

Fig. MS Windows 7 -
"network connection
details" window

0. The "Network connection details" window appears showing the IP address and the subnet mask of your PC.

19

Connection test - computer settings (Ethernet/TCP/IP connection)

ection test between your device and the required to integrate your device into the software. Access the device homepage via a web browser.

Procedure as follows for the connection test:

sure that the

first three blocks of the PC's IP address (see "Check the IP address of your computer", step 17) match those of the device IP address.

the last three digits (**xxx**) of the PC's IP address must be different from the last three digits of the device IP address.

subnet mask of your PC corresponds with that of your device.

e: IP address: 192.168.1.**xxx**

Subnet mask: 255.255.255.0

Find out the IP address of the device

Change to the *Configuration*

window - press button 1 "ESC".

Select the menu *Communication* menu

entry with button 3 and confirm with

button 6 "Enter".

Note the device IP address.

3. Send the "ping command"

1. Press the *Windows key* on your PC.
2. The Start menu appears with the search window.
3. Enter the command "cmd" in the search window and confirm with the "*Return key*".
4. The DOS window appears.
5. Enter the command "*ping*" (then a *space*) with your previously noted device IP address (e.g. "*ping 192.168.1.116*").
Note: Leave off the zeros at the start of the 3rd block!
6. Confirm with the "*Return key*".
7. If the "ping command" reaches the device, a positive response will be implemented.

NOTE!

Entering the IP address of your device in a web browser (e.g. "<http://192.168.1.116>") leads to the device homepage and so this checks the connection.

P mode "OFF" - adjust PC

If the device does not work without DHCP servers it is necessary to enter the IP address and the subnet mask itself. The gateway address is not required for configuration.

To require administrator rights for your PC you must set the DHCP communication protocol (DHCP mode) of the device to "**OFF**" by hand.

Example:
 Example IP address: 192.168.1.116
 Subnet mask: 255.255.255.0

In this case, set the computer as follows:
 IP address: 192.168.1.117
 Subnet mask: 255.255.255.0

In order to allocate an IP address for the PC via a direct connection between the PC and the device, please proceed as described up to including point 8, as described in step 10 for checking the IP address via the Control Panel.

Then proceed as follows:

- Click on the "Properties" button in the "Local area connection status" window.





Fig. MS Windows 7 - "Local area connection status" window

The "*Local area connection properties*" window appears.



4. The "*Internet protocol version 4 (TCP/IPv4) properties*" window appears.




Fig. MS Windows 7 - "Properties of internet protocol version 4 (TCP/IPv4)" window

Select the "*Internet protocol version 4 (TCP/IPv4)*" option in the "*Local area connection properties*" window and then click on the "*Properties*" button.

5. Select the "*Use the following IP address*" option and enter the "*Fixed IP address*" (and if necessary "*Subnet mask*") of your PC.
6. Click on "*OK*".

20

"ecoExplorer go" software settings



Install the software on your computer and proceed as follows:

Create a new project:

- Select "File" > "New project". For existing projects, select your project under "File" > "Open project".
- The "New project" window appears.
- Click the "Next" button under step 1 "Select project".
- Under step 2 "Project path", select the:
 - "Project name".
 - "Project path".
- Click on the "Done" button.
- Your project appears on the left in the "Projects" window in the working area.

Enter the new device into the project:

- Select "File" > "New file".
- The "New file" window appears.
- Under step 1 "Select file type", select the "File type" of your device in the "Measurement devices" category.

21

6. Select "Connection type" > "TCP/IP" in the selection list and enter the IP address of your device in the "Host" field (see step 18 "Read out the IP address of the device").
7. Click on the "Connection test" button.
8. If the connection test is successful, the "Display device information" window appears with the serial number, hardware version and firmware version.



The screenshot shows a Windows-style dialog box titled "Show device info". Inside, there is an information icon (an exclamation mark inside a circle) followed by the text: "Serial number: 5110-8033", "Hardware revision: 0041", and "Firmware version: 4.051 2014-02-02 10:00:00". At the bottom right of the dialog, there is a blue "OK" button, which is outlined with a red box to indicate it is the next action to be taken.

9. Click on the "OK" button.
10. Exit the "Add new device to the project" step by clicking on the "Done" button.
11. Configuring your device (see following steps).


"ecoExplorer go" software - device configuration

Basic settings

1. Open the context menu for your device with the right mouse button:
 - In the window "Projects" > "Your project" > "Devices" > "By device type" > "Energy Analyser 550" > "Device x".

2. Click on the "Configuration" menu item in the context menu.
3. The "Configuration [device x]" window appears in the right half of the working area.
4. Enter your individual device name in the "Name" field under the "Identity" menu of the "Configuration" window.



22

Select the connection variant for the voltage and current measurement of your device (see operating manual) in the selection lists under the "Connection variants" menu in the "Configuration" window.

Select the nominal frequency under "Nominal values" menu in the "Configuration" window, in accordance with the existing grid conditions. In order to identify events (over/undervoltage and overcurrent), enter the nominal values for all phases as references.

NOTE!


In order to avoid data loss, save your device configuration changes with the "Transfer" or "Transfer to" buttons!

NOTE!

This device configuration represents the basic settings. Further details for device settings required for different functions can be found in the operating manual (available online) for the software.

oExplorer go" software - recording settings

In "Recording configuration" you can link and configure which recordings the measurement device should save if required. A recording holds a measured value or the mean value of the measured value.



In order to be able to compare recordings of clients and events with those from other measurement points, activate the NTP mode under the "Time" menu and enter an NTP time server.

Weidmüller 