


Update Firmware PrintJet CONNECT

Alternative 1: Via Update.bin file on a USB-Stick


1. After you downloaded the zip-file from our Weidmüller homepage please unzip it and put the "Update.bin" file onto an empty USB-Stick



2. Connect the USB-Stick into 1 of the 2 USB-A ports of the PrintJet CONNECT.



3. The display screen will change from...




to...




Update Firmware PrintJet CONNECT

4. Please wait some minutes. When the following screen appears please click on “Start”




5. Wait until the firmware is installed completely. The PrintJet CONNECT will restart automatically. After the restart the firmware update is done.




Update Firmware PrintJet CONNECT

Alternative 2: Via Update helper program


1. After you downloaded the Updatehelper.exe file from our Weidmüller homepage. With a double click the program will start with a self-extraction



2. The program will start automatically. Please click on Continue/Weiter. Wait some seconds until the program has found the PrintJet CONNECT.




3. Wait some seconds until the program has found the PrintJet CONNECT. Click on Continue.




Update Firmware PrintJet CONNECT

- After some time the update has been send successfully. You can close the Updatehelper program now.



- Please wait 5-8 Minutes. When the following screen appears please click on “Start”



- Wait until the firmware is installed completely. The PrintJet CONNECT will restart automatically. After the restart the firmware update is done.

