

Timer (BTR)



Ordering data

Connection system	Type	Qty.	Order No.
Screw connection	BTR-S	1	8647720000
Tension clamp	BTR-Z	1	8647730000

Functions

Function A – on-delay

When the power supply is connected (A1/A2), the on-delay lasting for the set time T starts. The output R (15/18) connects the load at the end of the set time.



Note:

Switching of power supply stops the time function immediately.

