


Timing function



On-delay (E)

When the supply voltage U is applied, the set interval t begins. After the interval t has expired the output relay R switches into on-position. This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the expiry of the set interval, the interval t already expired is erased and is restarted when the supply voltage is applied next.

- 1 Time setting
- 2 Timescale
- 3 Status display (green): Supply voltage
- 4 Status display (yellow): Relays closed

Ordering data

Type	Order-No.
TFIS 24-240VUC 1CO ON	2697280000

